

# 00EDS-1078-00

## EDS Facemask

**EDS Facemask**  
for flight operations  
over 18,000 ft.



### DIRECTIONS FOR USE

1. Place mask over your face covering both nose and mouth area.
2. Slip elastic band over your head and adjust for comfort and fit. For best comfort, place straps below your ears.
3. Pinch noseclip to provide a seal around the nose.
4. Attach the other end of the tubing to the 6mm Blue outlet of the EDS unit and breathe normally.



2244 SE Airport Way, Suite 100 • Redmond OR 97756  
Telephone: (541)-548-7500 • Fax: (541) 923-4141  
[www.MHoxygen.com](http://www.MHoxygen.com) • [sales@MHoxygen.com](mailto:sales@MHoxygen.com)